

## **Townscape Corten Edging Installation**

## Screws

- **1.** Place hardwood pegs to determine the shape of the edging.
- 2. As additional, the edging can be ordered with pre-drilled holes so the pegs are easy to screw on. Screws are therefore included.
- **3.** Head size of the hardwood pegs is 50x50 mm. Pegs can be ordered in different heights of 400, 600 and 800 mm. The pegs are delivered in packs of 20 pieces. Per strip of 2300mm you need 4 edging pegs.



## Weld

- **1.** Place corten steel pegs to determine the shape of the edging
- **2.** Weld the corten steel edging in a flowing shape to the pegs.
- 3. Head size of the corten steel pegs is 30x30 mm and have a height of 600 mm. The pegs are delivered in packs of 20 pieces. Per strip of 2300mm you need 4 edging pegs.



## Weld/Screw

- **1.** Place corten steel roof support to determine the shape of the edging.
- 2. Weld or screw the corten steel edging in a flowing shape to the roof support. (Screws or rivets are not provided by us). Per strip of 2300mm you need 4 edging pegs.

  Note! Roof supports can only be

