


**OPERATION** 



#### **REMOVAL OPERATION - DETAIL**

CT30/CT40/CT50 Removeable Bollards use the same procedure







**R1** 

Remove Grub Screws (A) from Stainless Steel Sleeve (B) If Bollard has a sleeve


Remove Sleeve (B)


**Remove** Cap (C) from Steel Bollard (D)

# **OPERATION**



#### **REMOVAL OPERATION - DETAIL**





**R2** 

Remove all 6 sets of Screws and Nuts (E) from Covers (F)


Remove Covers (F) from Bollard Shoe (G)

Remove Padlock (H)

# **OPERATION**



# **REMOVAL OPERATION - DETAIL**




**R3** 

**Screw** M12 lifting insert (I) into Bollard Using Lifting Hoist (J) lift Bollard from Bollard Shoe





#### **REMOVAL OPERATION - DETAIL**



For Reinstallation of the CT30/CT40/CT50 Bollards use the same procedure in reverse

**R4** 

Attach cover (K) onto the Bollard Shoe using Nuts and Screws